






## Comparison Table of Remote Backup Solutions

Models	GV-Backup Center	GV-Redundant Server	GV-Failover Server
<b>Software Interface</b>			
<b>Supported Hosts</b>	GV-System, GV-IP Camera, GV-Video Server, GV-Compact DVR, GV-Recording Server <sup>(1)</sup>	GV-IP Cameras and 6 third-party IP camera brands on the connected GV-Systems / GV-VMS <sup>(2)</sup>	GV-IP Cameras and 6 third-party IP camera brands on the connected GV-Systems / GV-VMS <sup>(2)</sup>
<b>Features</b>	<ul style="list-style-type: none"> <li>• Backs up files already recorded by hosts</li> <li>• Supports up to 200 GV-IP Devices or 3 GV-Recording Server (128 ch each) or 12 GV-System (32 ch each)</li> </ul>	<ul style="list-style-type: none"> <li>• Records live view stream directly from IP cameras</li> <li>• Records an extra copy of the live view</li> </ul>	<ul style="list-style-type: none"> <li>• Records live view stream directly from IP cameras</li> <li>• Records when GV-Systems / GV-VMS fail to record</li> </ul>
<b>Supported Image Sources</b>	IP and analog <sup>(3)</sup>	IP	IP
<b>Operation Mode</b>	Application mode <sup>(4)</sup>	Service mode <sup>(4)</sup>	Service mode <sup>(4)</sup>
<b>Backup Mode</b>	<ol style="list-style-type: none"> <li>1. Round-the-clock backup</li> <li>2. Back up by schedule <sup>(5)</sup></li> </ol>	Round-the-clock recording of connected GV-Systems / GV-VMS	Round-the-clock recording when connected GV-Systems / GV-VMS fail to record
<b>Back Up by Event Types</b>	All events / Motion / IO <sup>(6)</sup>	Not Supported	Not Supported
<b>Playback</b>	Remote ViewLog, Web Query		
<b>License</b>	Dongle required		
<b>Max. License</b>	Up to 200 hosts	Up to 128 IP channels	Up to 128 IP channels

### Note:

1. Connection to GV-Backup Center is only supported by GV-Recording Server V1240 or later.
2. GV-Redundant Server and GV-Failover Server do not support GV-VMS hosts when they are running in service mode. It is highly suggested not to enable "Service Mode" on GV-VMS.
3. Analog cameras are connected through GV-Video Server, GV-Compact DVR, and GV-System.
4. Software in application mode can only run when a user account is logged in, whereas software in service mode can run in the background even when no account is logged in at the moment.
5. Back up by schedule is not supported when connecting to GV-Recording Server.
6. Back up by event types is only supported when connecting to GV-System. You can choose to back up all events types or selected event types only (motion and/or IO events).

All specifications are subject to change without notice.